


Automatic perfume dispenser manual



FUNCTION:

This model have an automatic photosensitive sensor to allows DAY only, NIGHT only or 24 HOURS operation. And the spraying interval can be set in to 5,15, 20 or 30 minutes.

LED Indicator:

1. When low power, the red LED indicator will blink, means need to change battery.
2. When spray more than 3000 times the green LED indicator will blink, means need to change perfume can.

OPERATION PROCEDURE:

1. Open the unit by gently pressing the button at the top of machine.
2. Put the batteries(2XAA) and fragrance can in relative apartment.
3. According to your need, move the right switch to choose which modes you need(DAY only, NIGHT only or 24 HOURS),and move the left swith to choose the spraying interval 5,15, 20 or 30 minutes.
4. Close the lid and put the machine at a proper place you want.
5. Spray testing: Turn on the maxhine, keep press the key1 button, then will spray one time.

NOTE:

1. The machine will spray one time when you first time to turn it on, pls keep away from the machine.
2. Please place the unit as high as possible and avoid spraying direct at human or delicate fabrics.